Dress With Skirt With Pleats - Выкройка #2376



Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper; 3 decorative buttons; 1 inner button.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back - cut 2
2. Lower back - cut 2
3. Upper front right - cut 1
4. Upper front left - cut 1
5. Lower front - cut 1 on fold
6. Stand collar – cut 2
7. Belt – cut 1

Fusible interfacing:

1. Stand collar – cut 1
2. Belt – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on upper backs, press bulk towards center. Sew upper back to lower back, press towards top and serge.

3. Sew darts on upper fronts, press bulk towards center. Sew the center seam of the upper front part, serge and press. Make and baste pleat on upper front.

4. On lower front, make left pleat, then right pleat, matching them against the marks for center piece. Baste them along upper edge. Sew upper front to lower front, press seam allowances towards top and serge.

5. Sew side seams and shoulder seams, sewing sleeve seams at the same time, press towards the back and serge.

6. Sew outer stand collar into the neckline of garment, press seam allowances towards stand collar. Serge the center back edges separately. Sew the center back seam from zipper mark to hem, press the seam apart. Sew in zipper.

7. Serge lower edge of inner stand collar. Pin together parts of stand collar, right sides together and sew along the upper edge. Clip seam allowances, stand collar turn right side out, straighten and press. Topstitch the inner stand collar into the seam between outer stand collar and the main piece.

8. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

9. Fold belt in half lengthwise right sides together and sew, and leave an opening unsewn along the lower edge, so that you can turn out the piece later. Turn belt right side out, straighten and press. Topstitch belt around all edges at 0.1 cm from the edge.

10. Make buttonholes on belt, sew on buttons. Sew on a button on upper front.

Технический рисунок:

