# Long Jacket - Выкройка #2467



Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

**О припусках на швы::**
*- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.*
*- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.*

**О требуемой длине ткани:**
*Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.*

## РАСКРОЙ:

**Обратите внимание при раскрое:**
*Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.*
*При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.*

Main fabric:
1. Back – cut 2
2. Side front – cut 2
3. Center front – cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Sleeve – cut 2

Fusible interfacing:
1. Center front facing – cut 2
2. Back neck facing – cut 1

## Инструкции:

1. Apply fusible interfacing. Apply additional tape of fusible interfacing along front neckline.

2. Sew dart on back. Press bulk towards center. Sew, serge and press apart center back seam.

3. Sew side front to front. Clip into curves. Serge and press towards the side piece.

4. Sew shoulder and side seams. Serge seams and press towards back.

5. Sew side seams of back neckline facing and central front facings, press seam apart. Serge the outer edge. Pin center front facings onto garment and sew center edges and neckline with one continuous seam. Trim seam allowances in corners, clip into curves, turn garment right side out, press. Slipstitch the facing and center front facings to shoulder seams and center back edge.

6. Sew sleeve seam. Serge and press towards back. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.

7. Serge the seam allowances for hem of garment and hem of sleeve, fold inside onto wrong side and topstitch.

## Технический рисунок:

