Dress With Elastic Tape On Waist - Выкройка #2478

Recommendations on fabric: natural/mixed knit fabric of medium stretchiness.



You will also need: knit bias tape; elastic tape, , its width should equal 0.5 cm.

Seam allowances: seam allowance for hem of garment — 2.0 cm, other seams 1 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

О работе с эластичными тканями:
Детали выкройки из трикотажа стачиваются специальным эластичным швом или швом зигзаг. Припуск на подгибку низа может быть настрочен двойной иглой для сохранения эластичности. Детали также можно стачать при помощи оверлока. При стачивании оверлоком, пожалуйста, обрежьте припуски на швы до ширины 0.6 - 0.8 см.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back – cut 1 on fold

2. Lower back – cut 1 on fold
3. Upper front — cut 1 on fold
4. Lower front — cut 1 on fold

Инструкции:

1. Sew right shoulder seam, press seam allowances towards back and serge.

2. Cut or use ready-made bias tape, its width should equal 4 cm length should equal the length of neckline + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew, fold the bias tape onto wrong side and topstitch onto main piece along the fold.

3. Sew left shoulder seam, press seam allowances towards back and serge.

4. Cut or use ready-made bias tape, its width should equal 4 cm length should equal the length of armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side and sew, fold the bias tape onto wrong side and topstitch onto main piece along the fold.

5. Sew side seams on lower and upper parts of the garment, press towards the back and serge.

6. Sew a gathering stitch along the upper edge of the lower part of the garment and gather fullness. Sew upper part to lower part, serge and press.

7. Serge the lower edge of garment, press onto wrong side and topstitch.

8. Cut a piece of elastic tape, its length should equal the waist girth minus 5 cm, and topstitch it to the seam allowance between the lower and the upper parts, stretching it as required.

Технический рисунок:

