Double Breasted Dress - Выкройка #2504



Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper; 4 buttons.

Seam allowances: all seams 1 cm; seam allowance for hem of garment and hem of sleeve – 2.0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 2
2. Side back - cut 2
3. Front — cut 2
4. Side front — cut 2
5. Sleeve – cut 2
6. Center front facing – cut 2
7. Back neck facing – cut 2

Fusible interfacing:
1. Back neck facing – cut 2
2. Center front facing – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Clip into seam allowance in the corner of the princess seam on the Back, serge the horizontal edge. Serge the lower edge of Side Back. Make and baste box pleats on the Backs according to markings. Sew side backs to center back, press towards center and serge.

3. Serge the center back edges separately. Serge the center back seam from neckline edge to the first marking and from the second marking down to hem, press the seam apart, pressing the slit for zipper at the same time. Sew in zipper.

4. Clip into seam allowance in the corner of the princess seam on the Front, serge the horizontal edge. Serge the lower edge of the Side Front. Make and baste box pleats on the Fronts according to markings. Sew side fronts to front, press towards center and serge.

5. Sew shoulder seams, clipping into the seam allowance of the shoulder seam on Front, press towards the back and serge. Sew collar seam, press the seam apart. Sew in the collar into the back neckline, press seam allowances towards the collar.

6. Sew the shoulder seams on Back Neckline Facing and Center Front Facings, clip into corners and press apart. Sew collar seam, press the seam apart. Sew the collar into the facing's neckline, press the seam apart. Serge the outer edge of center front facings and of neckline facing.

7. Pin facings and center front facings to front right sides together and sew center front edges and the collar edge. Clip into curves, turn collar right side out, straighten seams, press. Slip stitch together seam allowances along collar seams. Put right front onto left front, matching center lines and topstitch along the center front edge from notch to bottom.

8. Sew side seams, press towards the back and serge.

9. Sew sleeve seam, press towards back and serge. Sew sleeves into armholes, serge and press.

10. Serge hem of garment and lower edge of sleeve, press onto wrong side and topstitch.

11. Sew according to markings buttons, connecting the right and the left Fronts.

Технический рисунок:

