Dress With Asymmetrical Pleats - Выкройка #2515

Recommendations on fabric: natural/mixed fabric suitable for dresses.



You will also need: fusible interfacing, dress zipper.

Seam allowances: all seams 1 cm; seam allowance for hem of garment and hem of sleeve - 2.0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Attention! The pattern pieces are printed as seen from the right side. Turn them over when cutting from the wrong side of fabric!

Main fabric:
1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Upper front - cut 1

5. Lower front – cut 1
6. Front neck facing — cut 1
7. Back neck facing – cut 2
8. Sleeve — cut 2

Fusible interfacing:
1. Front neck facing — cut 1
2. Back neck facing – cut 2

Инструкции:

1. Apply interfacing to facings.

2. Serge the center back edges separately. Sew the center back seam from zipper mark to hem, press the seam apart, pressing the slit for zipper at the same time. Sew in zipper.

3. Sew side backs to center back. Serge seams and press towards center.

4. Make and baste pleats on lower front. Sew upper front to lower front. Serge and press towards top.

5. Sew side fronts to front. Serge seams and press towards center.

6. Sew side and shoulder seams, press towards the back and serge.

7. Sew the shoulder seams of the neckline facings, serge the outer edge. Pin facing to garment right sides together and sew the neckline. Clip into curves, turn the facing onto the wrong side, straighten and press. Slipstitch facing to shoulder seams and to zipper tape.

8. Sew sleeve seam, serge and press. Sew sleeves into armholes, matching notches. Serge and press.

9. Serge hem of garment and lower edge of sleeve, press onto wrong side and topstitch.

Технический рисунок:

