Blouse With Pleats On Shoulder - Выкройка #2537

Recommendations on fabric: natural/mixed fabrics suitable for blouses.



You will also need: dress zipper; fusible interfacing; 2 buttons.

Seam allowances: Seam allowance for hem of garment – 2 cm; other seams – 1 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 2
2. Front - cut 1
3. Sleeve – cut 2
4. Cuff – cut 2
5. Back neck facing — cut 2
6. Front neck facing – cut 1

Fusible interfacing:
1. Cuff – cut 2
2. Back neck facing — cut 2
3. Front neck facing – cut 1

Attention! Pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top.

Инструкции:

1. Apply fusible interfacing.

2. Serge the center back edges separately. Sew center back seam from notch for zipper to bottom. Press the seam apart. Sew in zipper.

3. Make and baste pleats on the left shoulder of the front. The inner part is directed towards armhole.

4. Sew side and shoulder seams, press towards the back and serge.

5. Sew the shoulder seams of the neckline facings. Clip seam allowances and press towards back. Serge the outer edge. Pin facing onto garment, right sides together and sew the neckline. Clip seam allowances, fold facing onto wrong side and press. Slipstitch facing to shoulder seams and center back edge.

6. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew a gathering stitch along the sleeve cap and gather fullness. Sew sleeves into armholes, serge and press. Sew a gathering stitch along lower edge of sleeve and gather fullness.

7. Fold cuff in half lengthwise, right sides together and sew side seams. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

8. Turn hem under inside two times by 1 cm and topstitch.

9. Make buttonholes and sew on buttons onto cuffs.

Технический рисунок:

