Loose Sweatshirt - Выкройка #2573

Recommendations on fabric: neoprene, natural/mixed knit fabric of small stretchiness. Knit fabric in two matching or contrasting colors.



You will also need: separating zipper.

Seam allowances: all seams 1 cm. Seam allowance along hem of garment – 1.5 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2

Main fabric 1:
1. Cuff – cut 2

Main fabric 2:
1. Stand collar – cut 1 on fold

Инструкции:

1. Serge the center edges of fronts. Sew the separating zipper to the center front edges.

2. Sew shoulder seams. Serge seams and press towards back.

3. Stand collar pin together in half lengthwise right side out and sew into neckline. Clip into seam allowance in the corner on front, sew along the horizontal edge. Serge the seam allowances.

4. Sew in sleeves. Serge the seam allowances and press onto sleeve. Sew side seams and sleeve seams. Serge seams and press towards back.

5. Make and baste pleats on sleeves. Sew cuff into ring. Fold cuff in half lengthwise and press. Sew the cuff to the sleeve, serge.

6. Make and stitch box pleats on front and on back. Baste the pleats by hand at the lower edge in order to fix them. Serge the seam allowance along the hem, turn inside and topstitch.

Технический рисунок:

