Blouse With Gathers - Выкройка #2576

Recommendations on fabric: natural/mixed fabrics suitable for blouses.



You will also need: fusible interfacing, elastic tape, its width should equal 1 cm, kapron tape or braid, 6 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm. Seam allowance for hem of sleeve – 1.5 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back – cut 1 on fold
2. Center back – cut 1 on fold
3. Side back – cut 2
4. Upper front – cut 2
5. Center front – cut 2
6. Side front – cut 2
7. Sleeve – cut 2

8. Center front facing – cut 2
9. Back neck facing – cut 1

Fusible interfacing:
1. Center front facing – cut 2
2. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew side backs to center back, press towards center and serge. Sew upper back to lower part, press towards top and serge.

3. Sew side fronts to front, press towards center and serge. Sew a gathering stitch along the lower edge of upper front and gather fullness. Sew upper front to lower front, press towards top and serge.

4. Cut a length of tape equal to the length of the shoulder edge (it is mentioned on the sewing pattern for back) + 2 cm at seam allowances. Sew gathering stitches along the shoulder edge of back and the shoulder edge of front and gather fullness. Sew shoulder seams, inserting the tape, press towards the back and serge.

5. Sew side seams, press towards the back and serge.

6. Sew shoulder edges of center front facings and back neckline facing, press the seam apart. Serge the outer edge.

7. Pin center front facings onto garment right sides together and sew the back neckline and the center front edges. Clip into curves, turn the center front facings onto wrong side, straighten, press.

8. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, serge and press.

9. Serge the lower edge of the sleeve, press onto wrong side and topstitch, making a casing. Thread the elastic tape into the casing, slipstitch.

10. Fold inside and press the hem seam allowance by 1 cm, then again at 1 cm and topstitch.

11. Make buttonholes on right front. Sew on buttons onto left front.

Технический рисунок:

