Sleeveless Wrap Dress - Выкройка #2590

Recommendations on fabric: soft natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing, dress zipper, decorative button.

Seam allowances: seam allowance for hem of garment — 2.0 cm, other seams 1 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back – cut 2
2. Back belt — cut 2
3. Lower back — cut 2
4. Upper front — cut 2
5. Front belt — cut 1
6. Lower front — cut 1 on fold
7. Center front facing — cut 2

8. Back neck facing – cut 1

Fusible interfacing:
1. Center front facing — cut 2
2. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on upper backs, press the inner part towards center. Sew back belt to upper part, press seam allowances towards belt and serge.

3. Make and baste box pleats on lower back. Sew upper back to lower back, press towards top and serge.

4. Serge center back edges separately on each piece. Sew center edge from neckline up to the first mark and from second mark to bottom, press the seam apart. Sew in zipper.

5. Sew darts on upper fronts, press the inner part towards center, cut away the bulk of the dart leaving 1 cm and serge.

6. Sew shoulder seams, clipping into the seam allowance of the shoulder seam on Front, press towards the back and serge. Sew collar seam, press the seam apart. Sew in the collar into the back neckline, press seam allowances towards the collar.

7. Sew the shoulder seams on Back Neckline Facing and Center Front Facings, clip into corners and press apart. Sew collar seam, press the seam apart. Sew the collar into the facing's neckline, press seam allowances towards the collar. Serge the outer edge of center front facings and of neckline facing.

8. Pin facings and center front facings to front right sides together and sew center front edges and the collar edge. Clip into curves, trim away corners, turn collar right side out, straighten seams, press. Slip stitch together seam allowances along collar seams. Put right front onto left front and baste together along lower edge.

9. Sew front belt to upper piece, press seam allowances towards belt and serge.

10. Make and baste box pleats on lower front. Sew upper front to lower front, press towards top and serge.

11. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side, leaving loose ends, and sew. Fold bias tape onto wrong side, clip into seam allowances and topstitch onto main piece along the fold. Press seam.

12. Sew side seams, press towards the back and serge.

13. Serge the lower edge of garment, press onto wrong side and topstitch.

14. Sew a decorative button onto the front belt.

Технический рисунок:

