Velvet Jacket - Выкройка #2616



Recommendations on fabric: natural/mixed velvet fabrics.

You will also need: fusible interfacing; lining; 9 buttons.

Seam allowances: all seams 1 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Back yoke – cut 1
3. Front yoke – cut 2
4. Front – cut 2
5. Stand collar - cut 2
6. Placket – cut 1
7. Center front facing – cut 2

8. Upper sleeve – cut 2
9. Lower sleeve – cut 2
10. Cuff – cut 2
11. Pocket welt – cut 2
12. Large pocket bag – cut 2

Lining:
1. Small pocket bag – cut 2

Fusible interfacing:
1. Stand collar – cut 1
2. Placket – cut 1
3. Center front facing – cut 2
4. Cuff - cut 2
5. Pocket welt – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Mark the pocket and apply fusible interfacing to this area. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags, serge.

3. Sew a gathering stitch along the upper edge of back and gather fullness. Sew back to back yoke, press seam allowances towards top and serge. Sew a decorative stitch along the seam at 0.5 cm. Sew a gathering stitch along the upper edge of front and gather fullness. Sew fronts to front yokes, press seam allowances towards top and serge. Sew a decorative stitch along the seam at 0.5 cm.

4. Serge outer edge of center front facing. Pin the center front facing to the front right sides together and sew center front edge. Press seam, fold center front facing onto wrong side and baste to the main piece along the neckline edge and the lower edge.

5. Sew shoulder and side seams, press towards the back and serge.

6. Pin together parts of stand collar, right sides together and sew the outer side. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Clip seam allowances. Stand collar turn right side out, straighten and press. Sew outer stand collar into neckline, press seam allowances towards stand collar. Fold the seam allowance of the inner side onto the wrong side and press and stitch in the ditch.

7. Fold placket in half lengthwise right sides together and sew short sides. Start and stop stitching exactly at the marked line of the placket seam. Turn right side out placket onto right side, straighten, press. Sew a gathering stitch along the lower edge of garment and gather fullness. Sew the outer side of placket to the garment, press seam allowances onto placket. Fold the seam allowance of the inner side onto the wrong side and press and topstitch into seam of.

8. Serge the elbow edges of the sleeve separately. Sew the elbow seam of sleeve from the cap to the mark, clip into seam allowance near the notch. Press the seam allowance on the area from sleeve cap to mark and sew a decorative stitch along the seam at 0.5 cm. Press apart the seam allowances on the area from the mark down to hem and sew decorative stitch along the edges at 0.1 cm. Sew and press apart front sleeve seam. Sew a gathering stitch along a sleeve cap and gather fullness. Sew sleeves into armholes matching notches.

9. Fold cuffs in half lengthwise right sides together and sew short sides. Start and stop stitching exactly at the marked line of the cuff seam. Turn cuff right side out, straighten and press. Sew outer side of cuff to lower edge of sleeve, press towards cuff. Fold the seam allowance of the inner side onto the wrong side and press and topstitch into seam of.

10. Make buttonholes on right front, sew on buttons on the left one. Make buttonholes and sew on buttons onto cuffs and onto stand collar.

Технический рисунок:

