Dress With Horizontal Seam Lines - Выкройка #2890



Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: dress zipper; bias tape (approximate length is given on the pattern piece for lower front); decorative tape (approximate length is given on the pattern piece for lower front).

Seam allowances: all seams 1 cm; hem allowance of the lower edge of the garment and the lower edge of the cuff — 0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back - cut 2
2. Lower back – cut 2
3. Upper front - cut 2
4. Lower front - cut 1 on fold
5. Sleeve – cut 2
6. Cuff — cut 2

Инструкции:

1. Sew darts on upper backs and upper fronts. Cut away the bulk of the dart to 1 cm, press towards the center and serge.

2. Sew upper back to lower back, press seam allowances towards top and serge.

3. Serge the center back edges separately. Sew the center back seam from zipper mark to hem, press the seam apart. Sew in zipper.

4. Sew the center seam of the upper front part, press the seam apart, serge. Topstitch the bias tape onto the seam. Sew upper front to lower front, press seam allowances towards top and serge.

5. Sew the shoulder seams and the side seams of the garment, press towards the back and serge.

6. Measure a length of bias tape for binding the neckline equal to the neckline length plus 4 cm. Press the bias tape flat in one plane, then fold it lengthwise in half with the right side out and press. Pin bias tape to neckline from the wrong side and sew. Fold bias tape onto right side and topstitch onto main piece along the fold.

7. Sew the cuff to the sleeve, press towards top and serge. Topstitch the bias tape onto the seam. Sew sleeve seam, press towards back and serge. Sew sleeves into armholes, serge and press.

8. Bind the lower edge of the garment and the cuffs with bias tape.

9. Topstitch the decorative trim onto the waist seam. Topstitch the trim onto the lower skirt panels according to the markings.

Технический рисунок:

