Dress - Выкройка #4753

Recommendations on fabric: natural/mixed fabric suitable for dresses.



You will also need: dress zipper; fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance along hem of lower backs and hem of front – 3.0 cm. Seam allowance along vent – 6 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back – cut 2
2. Back belt - cut 2
3. Lower back - cut 2
4. Lower front – cut 1 on fold
5. Front belt – cut 1
6. Side upper front - cut 2
7. Center upper front – cut 1 on fold

8. Back neck facing - cut 2
9. Front neck facing - cut 2
10. Front decoration - cut 2

Fusible interfacing:
1. Back neck facing - cut 2
2. Front neck facing - cut 2

Инструкции:

1. Apply interfacing to facings.

2. Sew darts on backs and lower front, press the inner part towards center.

3. Sew back belt to upper back, press seam allowances towards belt and serge. Sew lower back to back belt, press seam allowances towards belt and serge.

4. Serge center back edges separately. Trim away 5 cm on left center back along vertical edge of the vent. Apply interfacing to the vent on both sides of center back on the wrong side. Mark center seam line (vent fold-line) from the right side. Press left part along vent fold, on the right side press onto wrong side only the seam allowance of right side of vent (6 cm). Align pieces along center seam and baste together along upper edge of vent. Serge seam allowances of vent. Sew center back seam from mark to vent corner. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of the vent and sew them together by machine. Sew in zipper.

5. Sew front belt to lower front, press seam allowances towards belt and serge.

6. Serge upper edge of center upper front, press onto wrong side and slipstitch. Serge outer edge of front facing. Sew princess seams on front, inserting the center front between side front and front facing, press from center and serge. Straighten facing and fix it in place.

7. Press front decoration in half lengthwise wrong sides together. Pin right part onto left part and baste them together. Pin decoration onto upper front and baste together along edges. Sew front belt to upper front, press seam allowances towards belt and serge.

8. Sew side seams, press towards the back and serge.

9. Serge lower edge of back neckline facing. Pin back neckline facing onto self garment right sides together and sew upper edge exactly up to the marked shoulder seam line. Clip seam allowances.

10. Sew shoulder seams, placing them between back neckline facing and self garment. Press seams towards back, serge. Turn pieces right side out, press. Slipstitch seam allowances of back center seam to zipper tape.

11. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto edge of armhole from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.

12. Serge the lower edge of dress, press onto wrong side and finish with hidden stitches.

Технический рисунок:

