Waistcoat Dress - Выкройка #4758

Recommendations on fabric: natural/mixed fabric suitable for dresses.



You will also need: fusible interfacing; 3 buttons, 1 hidden button.

Seam allowances: all seams 1 cm; seam allowance for hem of dress – 3 cm; seam allowance along vent - 6 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Center back - cut 2
2. Side back - cut 2
3. Front — cut 2
4. Collar – cut 2
5. Center front facing- cut 2
6. Back neck facing – cut 1

Fusible interfacing:
1. Center front facing- cut 2
2. Back neck facing – cut 1

Инструкции:

1. Sew side backs to center back, press the seam apart. Trim away 5 cm along vertical edge of vent on left back. Apply fusible interfacing to vent area on backs from the wrong side. Mark center seam line (vent fold-line) from the right side. Press left part along vent fold, on the right side press onto wrong side only the seam allowance of right side of vent (6 cm). Align pieces along center seam and baste together along upper edge of vent. Serge center back edges separately. Serge seam allowances of vent. Sew center back seam up to vent corner. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of the vent and sew them together by machine.

2. Sew bust and waist darts on front. Press bulk of bust darts towards top, press bulk of waist darts towards center.

3. Sew side and shoulder seams, press towards the back and serge.

4. Pin upper collar to lower collar right sides together and sew collar end and collar fall. Trim seam allowances in corners snip into seam allowance near the mark, turn the collar right side out, straighten and press.

5. Pin the center front facing to the front right sides together and sew center front edge and lapel up to notch. Clip into seam allowance near the notch, turn pieces right side out, straighten, press.

6. Sew shoulder seams of center front facings and of back facing, press the seam apart. Serge outer edges.

7. Sew lower collar into the neckline of the main piece, and upper collar into neckline facings, press the seam apart, baste together. Slip stitch seam edges of center front facings (button stands) to shoulder seams on garment.

8. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto edge of armhole from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.

9. Serge the lower edge of dress, press onto wrong side and finish with hidden stitches.

10. Make buttonholes and sew on buttons. Sew on hidden button.

Технический рисунок:



