Coat With Hood - Выкройка #4796

Recommendations on fabric: natural/mixed fabric suitable for coats.



You will also need: lining; shoulder pads; sleeve heads; fusible interfacing; 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Center back – cut 1
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Hood – cut 2

8. Center hood – cut 1
9. Hood facing – cut 1
10. Center front facing – cut 2
11. Back neck facing – cut 1
12. Pocket welt – cut 2
13. Underlay piece – cut 2
14. Belt – cut 1

Lining:
1. Center back – cut 1
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Hood – cut 2
8. Center hood – cut 1
9. Large pocket bag — cut 2
10. Small pocket bag — cut 2

Fusible interfacing:
1. Center front — cut 2
2. Center front facing — cut 2
3. Hood facing – cut 1
4. Back neck facing — cut 1
5. Pocket welt – cut 2

Also apply fusible interfacing to armholes on back and front, pocket entrance, hem of garment and hem of sleeve.

Attention! Lining is cut using pattern blocks for self fabric, except for the width of center front facing and back neckline facing and facings капюшона.

Инструкции:

1. Apply fusible interfacing.

2. Sew shoulder darts on center back, press the inner part towards center. Sew side backs to center back, press the seam apart.

3. Sew side fronts to front, press the seam apart.

4. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew

welt to front along lower marked line of pocket. Topstitch underlay piece onto bigger pocket bag, folding long edge under. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew and serge edges of pocket bags.

5. Sew shoulder and side seams, press the seam apart.

6. Sew side hoods to center hood, press the seam apart. Sew hood into neckline, clip seam allowances, press apart.

7. Sew shoulder seams of central front facings and facings, press the seam apart.

8. Sew side hoods cut from lining to center hood, press the seam apart. Sew hood facing to hood lining, press the seam allowances towards the facing. Sew hood into neckline of center front facings and neckline facing, clip into curves, press apart.

9. Serge and press seam allowance along hem onto wrong side. Place center front facing onto front right sides together. Pin together center front facing and self garment and sew along center front and hood. Sew lower edge of the central front facing to front exactly according to the marked line of hem, stopping before the inner edge of the central front facing at 1.5 cm. Turn center front facings right side out onto right side, straighten seams. Baste together the seam allowances along neckline of hood close to the seam.

10. Sew the elbow seam of the sleeve and press it apart. Press seam allowance on lower edge onto wrong side. Sew and press apart front sleeve seam. Sew a line with short stitches along upper edge of sleeve cap. Собрать сборку and press gathered ease. Sew sleeves into armholes matching notches and adjusting ease. Sew shoulder pads and sleeve heads to garment.

11. Sew darts and seams on lining, sew in sleeves. Serge, fold inside and topstitch lower edge of lining. Sew lining to inner edges of the central front facings and to back neckline facing. Sew lining to hem of sleeve.

12. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening for turning. Trim seam allowances in corners, turn belt right side out. Sew the opening closed.

Технический рисунок:

