Two-Colour Blouson - Выкройка #4804

Recommendations on fabric: natural/mixed knit fabric of small stretchiness in contrasting or similar color.



You will also need: knit fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

О работе с эластичными тканями:
Детали выкройки из трикотажа стачиваются специальным эластичным швом или швом зигзаг. Припуск на подгибку низа может быть настрочен двойной иглой для сохранения эластичности. Детали также можно стачать при помощи оверлока. При стачивании оверлоком, пожалуйста, обрежьте припуски на швы до ширины 0.6 - 0.8 см.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric 1:
1. Upper back – cut 1 on fold
2. Upper front – cut 1 on fold

3. Sleeve inset – cut 2
4. Back neck facing – cut 1
5. Front neck facing – cut 1

Main fabric 2:
1. Lower back – cut 1 on fold
2. Lower front – cut 1 on fold
3. Sleeve – cut 2
4. Cuff – cut 2

Fusible interfacing:
1. Cuff – cut 2
2. Back neck facing – cut 1
3. Front neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew shoulder seams, press towards the back and serge. Sew sleeve inset to garment, press seam allowances towards the garment and serge.

3. Sew sleeve to lower back, press towards the back and serge. Sew sleeve to lower front, press towards front and serge.

4. Sew upper part to lower part, clipping into seam allowances near corners. Serge and press.

5. Sew side seams sewing the sleeve edges at the same time, press towards the back and serge.

6. Sew shoulder seams of facings, press the seam apart. Serge the outer edge. Pin facings to garment right sides together and sew the neckline. Clip into curves, turn the facings onto the wrong side and press. Baste facings to shoulder seams.

7. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise right side out and press. Pin cuff to wrong side of sleeve and sew to lower edge of sleeve, serge and press.Fold cuff onto right side and press.

8. Serge lower edge of garment, press onto wrong side and topstitch.

Технический рисунок:

