Asymmetrical Dress - Sewing Pattern #4822

Recommendations on fabric: natural/mixed knit fabric of medium stretchiness in contrasting or similar color.



You will also need: knit fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Upper back – cut 1
2. Upper front – cut 1
3. Sleeve – cut 2
4. Back neck facing – cut 1
5. Front neck facing – cut 1

Main fabric 1:

1. Lower back left – cut 1
2. Lower back right – cut 1
3. Lower front – cut 1

Fusible interfacing:
1. Back neck facing – cut 1
2. Front neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.

2. Sew darts on lower backs and on upper front. Press the waist darts toward the center and the bust darts upward.

3. Sew center seam on lower back, press towards left and serge. Sew upper back to lower back, press towards top and serge.

4. Make and baste pleats on lower front according to markings. Sew upper front to lower front, press towards top and serge.

5. Sew shoulder seams, press towards the back and serge.

6. Sew sleeves into armholes, press seam, serge. Sew sleeve seam and side seam continuously, press towards the back and serge.

7. Sew the shoulder seams of the neckline facings, serge the outer edge. Pin facing to dress right sides together, adjusting neckline edges, and sew. Clip into curves, turn the facing onto the wrong side and press. Slip stitch facing to shoulder seams.

8. Serge the hem of the garment and the hem of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

