Coat With Belt - Выкройка #4852

Recommendations on fabric: soft natural/mixed suiting fabrics.

You will also need: fusible interfacing; separating zipper; 2 grommets Ø = 2.5 – 3.0 cm.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Pocket welt – cut 2
7. Underlay piece – cut 2

8. Casing – cut 1
9. Belt – cut 1

Lining:
1. Large pocket bag — cut 2
2. Small pocket bag — cut 2

Fusible interfacing:
1. Center front facing — cut 2
2. Back neck facing — cut 1
3. Pocket welt – cut 2

Also apply fusible interfacing to armholes on back and front, pocket entrance, hem of garment and hem of sleeve.

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on front, press the inner part towards center, topstitch at 0.5 cm from seam.

3. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Topstitch underlay piece onto bigger pocket bag, folding long edge under. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew and serge edges of pocket bags.

4. Pin fronts right sides together and adjust edges, measure the length of center front edges. Sew zipper to the center front edge.

5. Sew shoulder seams, press towards the back and serge.

6. Sew sleeves into armholes, serge and press.

7. Sew side seams sewing the sleeve edges at the same time, press towards the back and serge.

8. Sew shoulder seams of central front facings and facings, press the seam apart. Serge the outer edge.

9. Serge and press seam allowance along hem onto wrong side. Place center front facing onto front right sides together. Pin together center front facing and top of garment and sew along the center front edge and along neckline. Sew lower edge of the central front facing to front exactly according to the marked line of hem. Turn center front facings right side out onto right side, straighten seams. Sew a decorative stitch along center front

and neckline at 0.5 cm.

10. Serge lower edge of sleeve, press onto wrong side and topstitch. Topstitch hem.

11. Press seam allowances of casings onto wrong side, pin it onto Shell according to markings from the wrong side and topstitch along two longer edges at 0.1 cm from the fold. Install grommets according to markings.

12. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening for turning. Trim seam allowances in corners, turn belt right side out. Sew the opening closed. Thread belt into casing and grommets.

Технический рисунок:

