Classical Coat - Sewing Pattern #4865



Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 5 buttons; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper collar – cut 1
6. Lower collar - cut 1
7. Upper sleeve – cut 2

8. Lower sleeve – cut 2
9. Back neck facing – cut 1
10. Center front facing – cut 2
11. Belt – cut 1

Lining:
1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Pocket bag – cut 4

Attention: Lining for back and front is cut using pattern pieces for main fabric except for back neckline facing and central front facings correspondingly.

Fusible interfacing:
1. Center front – cut 2
2. Center front facing — cut 2
3. Upper collar – cut 1
4. Back neck facing — cut 1

Fusible interfacing is also applied to seam allowances along armhole on the back, hem of garment, hem of sleeve and seam allowance along pocket entrance.

INSTRUCTIONS:

1. .

2. , . , . , .

3. , . . , . , . .

4. , .

5. . . , . , .

6. , .

7. , ... 0,2 . , .

8. . .

9. . . . . .

10. , . . .

11. . . .

12. . . ,

13. , . . , , . .

TECHNICAL DRAWING:

