Dress With Wrap Imitation - Выкройка #4951

Recommendations on fabric: light natural/mixed fabric suitable for dresses.



You will also need: lining; dress zipper, 2 buttons.

Seam allowances: all seams 1 cm; seam allowance for hem of dress – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Upper back - cut 2
2. Back belt — cut 2
3. Lower back - cut 2
4. Upper front – cut 2
5. Lower front — cut 1 on fold
6. Front belt - cut 2
7. Belt facing - cut 1

Lining:
1. Upper back – cut 2
2. Upper front – cut 2

Инструкции:

1. Make and baste pleats along upper edge of lower fronts and lower backs. Fold bulk towards center.

2. Sew darts on backs and on lining of backs, press bulk towards center.

3. Sew shoulder and side seams on shell and lining. Press the seam apart.

4. Pin upper dress to lining right sides together and sew neckline. Sew armhole in two steps: first, sew the front armhole, then sew the back armhole. Clip into seam allowances on curves, fold lining towards wrong side.

5. Baste shell to lining along lower edge. Sew a gathering stitch along lower edge of upper front between the markings and gather fullness.

6. Sew front belts to back belt. Serge seams and press towards back.

7. Sew belts to upper fronts and to upper backs, serge and press towards bottom. Pin belt facing onto right part of belt and sew along middle and lower edges. Start and stop stitching exactly at the marked seamline. Clip into lower seam allowance of belt and of facing, stopping at 0.1 cm from the stitch line. Cut the seam allowance in the corner, fold onto wrong side. Clip into upper seam allowance of facing at the end of the marked upper stitch line. Fold inside upper seam allowance facings inside and topstitch into seam of. Pin right part of dress onto left part of dress, baste together along center line and sew belt facing and left front belt. Serge.

8. Sew side edges of lower parts of dress. Serge seams and press towards back. Sew dress skirt to dress bodice, folding away the right upper front. Markings on lower belt correspond to the center pleats.

9. Serge center back edges separately. Sew center back seam from notch for zipper to bottom, press the seam apart. Sew in zipper.

10. Serge lower edge of dress, press onto wrong side and topstitch.

11. Sew decorative buttons at belt.

Технический рисунок:

