Vest With Slanted Hem - Выкройка #4980

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: lining; fusible interfacing; 2 buttons; buckle.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 4 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 2
2. Side – cut 2
3. Front – cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Flap – cut 4
7. Pocket facing – cut 4

8. Belt – cut 1
9. Belt Loop – cut 1

Lining:
1. Back – cut 2
2. Side – cut 2
3. Front – cut 2
4. Pocket bag – cut 4

Attention! Lining for back and front is cut using pattern blocks for shell, except for the width of back neckline facing and center front facing.

Fusible interfacing:
1. Front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Flap – cut 2
5. Pocket facing – cut 4

Инструкции:

1. Apply fusible interfacing.

2. Sew side backs to center back, press towards center. Sew center back seam, press the seam apart.

3. Slash front along the pocket line, stopping at 1 cm from the vertical dart side. Sew the dart, trim bulk to 1 cm and press apart. Fix pocket opening with fusing or baste together. Sew side front to center front, press the seam apart.

4. Pin together flaps right sides together and sew three sides. Trim the seam allowances at the corners of the flaps, clip into curves, turn right side out. Sew a decorative stitch at 0.5 cm from the edge.

5. Mark the position of pocket. Fold pocket facings in half wrong sides together and press. Mark the stitch line on pocket facing parallel to the facing fold line. Mark an additional line on pocket flap for sewing it parallel to the upper edge of pocket flap, verifying the width of pocket flap all along. Mark additional lines parallel to pocket opening for sewing pocket flap and pocket facings. Sew pocket lining to pocket flap. Sew facings to front. Finish stitching at the guidance lines that you marked near pockets. Check the accuracy of sewing the facings on the wrong side (stitch lines should be parallel). Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn facings onto wrong side through the resulting opening, straighten edges, adjust ends of facings so that the pressed fold lines of the facings meet one another. Sew a double back stitch lines near corners to fix ends of pockets. Insert flap ito pocket and sew it to upper pocket facing. Pin lower lining of pocket onto the seam of lower facing and stitch-in-the-ditch; trim and sew pocket lining.

6. Sew shoulder seams, press the seam apart.

7. Sew center collar seam, press the seam apart. Sew one-piece collar into neckline, clipping into seam allowance near corner, clip seam allowances and press apart.

8. Sew shoulder seams of back neckline facing and center front facings, press the seam apart. Sew center collar seam, press the seam allowances apart. Sew one-piece collar into neckline facings, clipping into seam allowance near corner, clip seam allowances and press apart.

9. Pin center front facing onto front right sides together and sew around center front and collar. Clip into curves, trim away corners. Turn the center front facings onto wrong side and press.

10. Sew seams on lining, leaving an opening for turning in the right side seam. Press.

11. Sew lining to the central front facings and to facing, press seam. Turn garment right side out, straighten seams. Slip stitch together seam allowances along collar seams.

12. Sew lining to lower edge of garment. Turn right side out through the opening. Sew armholes in two steps: first back armhole, then front armhole. Sew the opening closed.

13. Sew a decorative stitch along hem and center front at 4 cm from the edge.

14. Make buttonholes on front. Sew on the main button and the hidden button.

15. Serge one longer edge of the belt loop. Fold belt loop so that it has 3 layers in total and topstitch along longer sides. Cut belt loop into 4 parts. Topstitch belt loops onto princess seams at the waist level.

16. Fold belt in half lengthwise right sides together and sew along longer and one shorter sides. Turn belt right side out, press. Serge the shorter side. Sew a decorative stitch around the contour at 0.5 cm. Thread in and fix buckle on the serged side of the belt. Make holes.

Технический рисунок:



