

Sewing Pattern — Sport shirt 4272

Recommendations on fabric: natural / mixed knitted fabric of medium stretchiness.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: hem and lower edge of sleeve – 1.5 cm, all other seams - 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back part – 1 detail
2. Central front part – 1 detail
3. Side front part – 2 details
4. Sleeve – 2 details

Advice:

Knitted fabric details are sewn together with special elastic or narrow zig-zag stitch. When serging cut seam allowances to 0.6 – 0.8 cm. Seam allowance on turnup is stitched with twin needles to save stretchiness.

INSTRUCTIONS:

1. Stitch side front part to central front part. Serge seams and press them towards center.
2. Sew right shoulder edge. Serge and press the seam towards back part. Cut bias tape of 4 cm wide and as long as neckline. Fold the bias tape in half wrong sides together and press. Put the bias tape onto wrong side of neckline and stitch. Turn to right side and topstitch. Sew left shoulder edge. Serge and press seam allowance towards back part. Make barred end on neckline at shoulder seam level.
3. Sew sleeve into armhole, matching notches. Serge and press seams.
4. Sew side seams together with edge of sleeve. Serge seam allowances.
5. Serge hem of garment and lower edge of sleeve. Fold to wrong side, press and topstitch.

TECHNICAL DRAWING:

