

Sewing Pattern — Overalls 5240

Recommendations on fabric: cotton jersey.

You will also need: elastic lace; 4 clasps; jersey iron-on interfacing.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Bottom front – 2 pieces
2. Bottom back – 2 pieces
3. Top back - 1 folded piece
4. Top front - 1 folded piece
7. Back neck edging – 1 piece
8. Front neck edging – 1 piece
9. Armhole edging – 2 pieces

Lace:

5. Back inset - 1 folded piece
6. Front inset - 1 folded piece

INSTRUCTIONS:

1. Stitch the side seams. Fold the integrated facings of the shoulder fastenings to the wrong side according to the marks and tack it to the garment.
2. Stitch the armhole's edging side edges together. With right sides together, pin the edging to the garment along the armhole edges and stitch 0,7 cm in from the edges. Flip the edging over to the wrong side and fold the raw edges under. Topstitch them on the previously made seams.
3. Stitch the bottom side/inside leg edges and the crotch seam. Gather the waist edge slightly.

4. Stitch the side seams of the insets. Sew the insets to the lower edges of the bodice and to the top bottom edge stretching them slightly.
5. Fold the trousers hems to the wrong side, fold the lower raw edges under and stitch them in the place.
6. Fix the top parts of the clasps to the front fastening. Fix the bottom parts of the clasps to the back fastening.

TECHNICAL DRAWING:

