

Recommendations on fabric: whipcord (polyester, cotton or mixed fabric).

You will also need: fusible interfacing, two pocket zippers (zip length depends on pocket opening length), elastic of 4.5 cm wide, cord, velcro tape.

Seam allowances: hem of trousers – 5.5 cm, other seams – 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:


Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Main fabric:

1. Front - cut 2 (A)
2. Back - cut 2 (B)
3. Yoke - cut 2 (C)
4. Waistband - cut 1 (D)
5. Off-set welt - cut 2 (E)
6. Small pocket bag - cut 2 (F)
7. Big pocket bag - cut 2 (G)
8. Back pocket back - cut 2 (H)



INSTRUCTIONS:

1. Cut a bias tape of 3.5 cm wide for piping or use ready-made. Tape length depends on piping length. Note: After piping is ready, it should have 1 cm of seam allowances.
2. To make piping: Fold bias tape in half lengthwise, lay cord along the inside fold and sew next to the cord with a piping foot.
3. Pockets: Apply fusible interfacing to welt, fold in half along center line and press. Apply fusible interfacing to pocket opening. Mark a line on welt which shows the width of welt when ready. Topstitch piping on outer side of welt. Lay welt on right side of front piece matching pocket marking line with line on welt. Outer side of welt must match with right side of front piece. Sew welt. Cut pocket opening in center between marking lines making slant cuts to corners. Turn welt to inside. Press seam open. Lay zipper under pocket opening. Sew zipper from right side of front at 0.1 cm from pocket opening. Sew small pocket bag to lower zipper tape and turn it down. Sew big pocket bag to upper zipper tape. Sew bags together. Edges of pocket bags should go into waistband connecting seam.
4. Back pocket: Sew yoke pieces together. Sew pocket bag to right yoke inserting piping. Sew pocket bag to right back piece, turn out, press and topstitch velcro tape. Sew backs together. Sew pocket bags together. Sew yoke to back. Make bartacks on pocket opening. Topstitch center back seam on left back piece.
5. Shorts: Press hem of shorts. Turn under first at 1 cm, then again at 4.5 cm (Unfold before sewing side seams and leg seams). Sew side seams to slit mark. Topstitch along side seam. Sew center front seam. Top stitch on left front piece. Sew leg seams.
6. Waistband: Mark lines for stitching elastic on waistband. Make two holes for cord between marked lines on front near center seam. Distance between holes is 8 cm. Sew waistband into ring. Sew elastic into ring. Set elastic into waistband, stretch and make two stitches along elastic. Sew waistband to shorts catching elastic into seam.
7. Hem: Fold hem allowance along previously pressed lines and topstitch.
8. Press shorts. Thread the cord through the waistband.

TECHNICAL DRAWING:

