

Sewing Pattern — Top 4291

Recommendations on fabric: natural / mixed medium stretch knit

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: hem, lower edge of sleeve and neckline — 1.5 cm, all other seams - 0.7 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.

CUTTING:


(On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Advice:

Knit fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hem is stitched with twin needles to save stretchiness. Pieces can also be sewn together with 3 or 4 – thread serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

Fabric:

1. Upper back – cut 2
2. Lower back – cut 2
3. Upper front – cut 2
4. Lower front – cut 1
5. Sleeve — cut 2
6. Front waistband — cut 1
7. Back waistband— cut 1
8. Strap — cut 2



INSTRUCTIONS:

1. Sew center edge of upper and lower backs. Serge seam allowances and press toward left.
2. Sew shoulder seams. Serge and press seam allowances towards back.
3. Serge neckline/ front edge. Turn seam allowance under and topstitch.
4. Make a gathering stitch on lower edge of upper front to first notch and gather. Put right part on top of left one, match edges and baste.
5. Sew front waistband to upper front. Sew back waistband to upper back. Serge seam allowances.
6. Sew back and front lower parts to the waistband. Serge seam allowances.
7. Fold the strap right sides together and sew the long edge. Turn the strap right side out and press. Loop the strap around upper front at marks, and tack to armhole.
8. Sew sleeve into armhole, matching notches. Serge and press.
9. Sew side seams together with the edge of sleeve. Serge seam allowances and press toward back.
10. Serge bottom edge of garment and sleeve. Turn seam allowance under, press and topstitch.

TECHNICAL DRAWING:

