

## Coat With 3/4 Sleeves - Sewing Pattern #4470

Recommendations on fabric: Natural/mixed fabric suitable for coats.

You will also need: lining; buckle for belt; 2 buttons; shoulder pads; fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Upper sleeve - cut 2
6. Lower sleeve - cut 2
7. Back neck facing - cut 2

8. Center front facing – cut 2

Lining:

1. Center back – cut 2
2. Center front – cut 2
3. Side back – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Pocket bag — cut 4

Fusible interfacing:

1. Center front — cut 2
2. Center front facing — cut 2
3. Back neck facing — cut 2

Fusible interfacing is also applied to parts of armholes on back, pocket opening, vent of back and vent of sleeve and lower edge of garment.

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Sew darts on back, press bulk towards center. Sew side backs to center back, press seam apart. Apply fusible interfacing to vent areas on the back on the wrong side. Mark center seam line (vent fold-line) from the right side. Press left back along fold line of vent. Align pieces along center seam. Sew center back seam and corner of vent, stop stitching when the distance from vertical edge of vent is 1 cm. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of vent and topstitch them from the right side using machine stitch.
3. Sew darts on front, press bulk towards bottom. Sew pocket bag to center front and to side front. Sew side fronts to center front, sewing the pocket bag edge at the same time. Press seam apart, clipping into corner on side front. Press pocket towards center.
4. Sew shoulder and side seams, press seam apart.
5. Sew elbow seam of sleeve and press towards top. Sew vent on sleeve (see instructions). Sew and press apart front sleeve seam. Sew a line with short stitches along upper edge of sleeve cap. Gather fullness and press gathered ease. Sew sleeves into armholes matching notches and adjusting ease. Sew shoulder pads and sleeve heads to garment.
6. Sew shoulder seams of buttonstands and facings, press seam apart.

7. Press seam allowance on lower edge of garment. Place center front facing onto front right sides together. Pin together center front facing and top of garment and sew along the center front edge and along neckline. Sew lower edge of buttonstand to front exactly according to the marked line of hem, stepping back from inner size of buttonstand at 1.5 cm. Turn center front facings right side out onto right side, straighten seams.
8. Sew seams on lining, leaving an opening in left side seam for turning. Sew in sleeves. Sew lining to buttonstands and facing. Sew lining to lower edge of garment. Turn coat right side out through the opening. Sew the opening closed.
9. Make buttonholes on right front, sew on buttons on left front. Sew buttons to vent of sleeve.

## **TECHNICAL DRAWING:**

