

Recommendations on fabric: natural/mixed fabric suitable for blouses.

You will also need: invisible zipper.

Seam allowances: 1 cm for all seams, 1.5 cm for hem.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:


Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Main fabric:

1. Collar - cut 1 (A)
2. Back – cut 2 (B)
3. Front - cut 1 (C)



INSTRUCTIONS:

1. Sew shoulder and waist darts on front and backs. Press bulk towards center. Sew bust darts on front. Press bulk upwards.
2. Sew center back seam. Serge and press seam towards left side.
3. Sew shoulder seams. Serge and press seams towards back.
4. Serge separately left side edges. Sew left side seam from armhole to first mark, and from second mark down to hem. Press seam open. Install zipper. Sew right side seam. Serge and press seam towards back.
5. Fold collar in half lengthwise right sides together and sew ends to "o" mark. Trim seams at mark and in corners. Turn collar right side out, straighten and press. Sew outer collar into neckline, clip seam in front's corner. Turn inner collar edge under and topstitch into connecting seam. Press ready collar placing connecting seam in center of inner side.
6. Cut a bias tape of 4 cm wide from main fabric. Length is equal to armhole length + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to armhole from right side and sew. Turn bias tape to inside and topstitch along the fold. Press.
7. Serge lower edge of blouse, turn under and topstitch.
8. Cut a rectangle of 10x5 cm from main fabric for a strap. Fold piece in half lengthwise right sides together and sew long edge. Turn strap right side out, straighten and press. Place collar ties together, wrap them with the strap, adjust the length and fasten.

TECHNICAL DRAWING:

