

2528 - Sewing Pattern #2528

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing.

Seam allowances: seam allowance for hem of garment - 1.5 cm, other seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Front - cut 1 on fold
2. Back - cut 2
3. Collar - cut 4

Fusible interfacing:

1. Collar - cut 2

INSTRUCTIONS:

1. Sew center back seam. Serge and press towards left.
2. Sew front darts, press bulk towards top.
3. Sew center seams of collars pairwise, press seam apart. Pin collars together right sides together and sew along outer edge. Clip seam allowances, turn collar right side out, straighten, press. Pin right collar onto left collar and baste together along lower edge. Sew collar into the front neckline, slashing corners, serge and press.
4. Sew shoulder seams (start and stop stitching exactly at the marked line of the collar seam). Press seams towards back and serge. Sew collar into back neckline, slashing corners, serge and press.
5. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to armhole edge from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the seam. Press seam.
6. Sew side seams, press seams towards back and serge.
7. Serge lower edge of garment, press onto wrong side and topstitch.

TECHNICAL DRAWING:

