

## Jacket With Hood - Sewing Pattern #2877

Recommendations on fabric: natural/mixed fabrics suitable for raincoats, eco leather or natural leather.

You will also need: lining; fusible interfacing; separating zipper; decorative cord; 2 grommets; 2 cord end caps; 2 non separating zippers for pockets.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Front yoke - cut 2
4. Sleeve - cut 2
5. Back neck facing - cut 1
6. Center front facing - cut 2

7. Hood – cut 2
8. Center hood – cut 1
9. Hood facing – cut 1

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Hood facing – cut 1

Lining:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Hood lining – cut 2
5. Center hood – cut 1
6. Large pocket bag – cut 2
7. Small pocket bag – cut 2

Back lining is cut using the pattern pieces for the main fabric, except for the width of back neckline facing.

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Mark the position of pockets with parallel lines. Cut the slit for pocket opening. Slash diagonally at 1-1.5 cm from the end of the marked slit. Turn the seam allowances onto the wrong side through the resulting opening, straighten edges. Pin zipper under the opening so that you can see the teeth and sew. Sew right side of lining to the wrong side of zipper tape. Sew edges of lining.
3. Sew front yoke to front. Press towards top. Sew a decorative stitch at 0.5-0.7 cm from seam.
4. Sew shoulder seams, press the seam apart.
5. Sew sleeves to garment, press seam allowances towards sleeve. Sew side seams, sewing the sleeve edges at the same time, press towards the back.
6. Sew side hoods to center hood, press seam allowances towards center part. Install grommets on hood.
7. Sew hood into neckline, press the seam apart.
8. Sew shoulder edges of center front facings and back neckline facing, press the seam apart. Sew hood pieces from lining to the central piece, press seams onto center part. Sew facing to hood lining, press the seam allowances towards the facing. Sew hood into neckline of center front facings, press the seam apart.

9. Pin center front facings and hood to the main piece right sides together and sew around the outer edge of center front facings and hood, inserting the zipper. Clip into curves, trim away corners. Turn the center front facings onto wrong side, straighten, press. Baste together seam allowances of the hood seam. Sew a fixing stitch along center front at 0.5-0.7 from the edge. Sew a fixing stitch along the outer edge of the hood, making a casing.

10. Sew the pieces from lining, leaving an opening in left side seam. Sew lining to facing, center front facings, to hem of jacket. Turn the garment right side out through the opening. Sew lining to hem of sleeve through the opening, press seam. Sew the opening closed. Sew a decorative/fixing stitch along hem of jacket at 2 cm from the edge.

11. Thread cord into casing, attach cord ends.

## **TECHNICAL DRAWING:**

