

## Sewing Pattern — Top 5664

Recommendations on fabric: middle/high stretchable jersey (natural or mixed).

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1.5 cm for the hem/sleeve hems, 1 cm for other seams.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Back part – 1 piece
2. Front part – 1 piece
3. Sleeve – 2 pieces

**OUR ADVICE:** stitch jersey details with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances till 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

### **INSTRUCTIONS:**

1. Stitch shoulder front/back edges. Neaten seams and press them backwards. Slash the allowances into front/back armhole at notch. Neaten armhole upper segment, fold it in and topstitch.
2. Neaten sleeve cap's straight edge. Fold it under and topstitch.
3. Stitch side front/side back edges. Neaten seams and press them backwards.
4. Stitch sleeve seams. Neaten seams and press them.
5. Stitch the sleeve into armhole coinciding notches. Neaten seams and press them.
6. Neaten the hem/sleeve hem/neckline. Press them into wrong side and topstitch.

**TECHNICAL DRAWING:**

