

Sewing Pattern — Top 5623

Recommendations on fabric: natural/mixed fabric

You will also need: fusing; piping; 1 button.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 0 cm for neckline/armholes, 1 cm for other seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back part – 1 piece
2. Front part – 1 piece
3. Waistband – 2 folded pieces

Fusing:

1. Waistband – 1 piece

INSTRUCTIONS:

1. Apply the fusing to wrong side of the waistband.
2. Cut a “drop” into wrong part.
3. Press the piping along the center and overstitch “drop”’s edge.
4. Overstitch front/back neckline with the piping making a loop in right front part.
5. Stitch front darts. Press darts upward.
6. Overstitch armholes with the piping making a strap of the piping. Regulate strap’s length during fitting-on.

7. Stitch left side seam leaving a lit for the waistband. Neaten the seam and press it apart pressing slit edges.
8. Stitch right side edge. Neaten right side seam and press it backward.
9. Overstitch the waistband beginning at the notch, overstitching waistband's ends, and along lower edge. Turn the waistband right side out and press it.
10. Make loose stitches at 0.5 cm from lower edge along the hem. Gather the fabric slightly.
11. Stitch waistband's right side to the garment Press the seam toward the waistband. Press waistband's open edge downward and topstitch along the seam.
12. Sew the button on left front part.

TECHNICAL DRAWING:

