

## Sewing Pattern — Top With Shaped Front 5619

Recommendations on fabric: sheer natural/mixed fabric.

You also need: piping; concealed zip.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 0 cm for neckline edges, 1.5 cm for the hem, 1 cm for other seams.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Back part – 2 pieces
2. Front yoke – 1 piece
3. Upper front part – 2 pieces
4. Lower front part – 1 piece
5. Front sleeve – 2 pieces
6. Back sleeve – 2 pieces

### **INSTRUCTIONS:**

1. Stitch back waist darts. Press darts toward back center.
2. Neaten middle back edge. Stitch middle back seam up to closure notch. Press middle seam apart, press closure slits. Stitch the zipper in.
3. Make loose stitches at 0.5 cm from upper front part's lower edge. Gather the fabric between notches.
4. Stitch shoulder edges together. Neaten shoulder edges and press them backward.
5. Press the piping along the center and overstitch neckline and armholes.
6. Fold piping's ends under and sew them to back part by hand.
7. Stitch upper front part to the yoke. Neaten the seam and press it toward the yoke. Process the left detail first, then process right detail. Make fixing stitch into yoke's upper corner.
8. Stitch lower part to front part. Neaten the seam and press it toward the yoke.

9. Slash seam allowances into sleeves as marked. Turn in open edges with 0.5 cm width seams. Stitch shoulder seam between sleeve cap and the notch. Neaten the seam and press it backward.
10. Slash front/back seam allowances at armholes' notches. Stitch sleeves into open armholes. Neaten seams and press.
11. Stitch side edge. Neaten the seam and press it backward. Neaten armholes' open edges leaving 0.5 cm seam allowance. Fold the seam under and topstitch. Press armholes.
12. Neaten top hem, fold it into wrong side and topstitch at 1.5 cm from the edge.

**TECHNICAL DRAWING:**

