

Dress - Sewing Pattern #2164

Recommendations on fabric: soft natural/mixed fabric suitable for dresses.

You will also need: dress zipper; 5 buttons; elastic tape, its width should equal 1 cm.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper back – cut 2
2. Center back – cut 2
3. Side back – cut 2
4. Upper front – cut 1 on fold
5. Center front – cut 1 on fold
6. Side front – cut 2

7. Sleeve – cut 2

INSTRUCTIONS:

1. Sew princess seams of lower back (sew side backs to center back), press towards center and serge. Sew upper back to lower part, press towards top and serge.
2. Serge center back edges separately. Sew the center back seam from zipper mark to hem, press the seam apart. Sew in zipper.
3. Sew darts on upper fronts, press the inner part towards center. Sew princess seams on lower front (sew lower side fronts to lower center front), press seams towards center and serge. Sew upper front to lower front, press towards top and serge.
4. Sew shoulder seams, press towards the back and serge.
5. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of neckline + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the seam. Press seam. Slipstitch the ends of the bias tape to zipper tape.
6. Cut two ties on bias, 2.5 wide and 50 cm long. Fold tape in half lengthwise right sides together and stitch at 0.5 cm from fold. Turn the tie right side out and straighten it. Turn under one of the ends and stitch.
7. Sew side seams, inserting the ties, press towards the back and serge.
8. Sew sleeve seam, serge and press. Sew a gathering stitch along the sleeve cap and gather fullness. Serge lower edge of sleeve, press onto wrong side and topstitch.
9. Cut a piece of elastic tape, the length should equal the overarm girth at the biceps area. Sew it into a ring. Topstitch the elastic tape onto the sleeve along the marked line, from the wrong side.
10. Sew sleeves into armholes, serge and press.
11. Serge hem of garment, press onto wrong side and topstitch.
12. Sew on decorative buttons onto upper front.

TECHNICAL DRAWING:

