

Blouson With Yoke - Sewing Pattern #2294

Recommendations on fabric: natural/mixed fabrics suitable for dresses or blouses.

You will also need: fusible interfacing; dress zipper.

Seam allowances: all seams 1 cm; seam allowance for hem of garment – 2.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 1 on fold
3. Front yoke - cut 1
4. Sleeve - cut 2
5. Cuff - cut 2
6. Back neck facing – cut 2
7. Front neck facing – cut 1

8. Belt – cut 1

Fusible interfacing:

1. Back neck facing – cut 2
2. Front neck facing – cut 1
3. Cuff - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Serge center back edges separately. Sew center seam from notch for zipper down to hem, press the seam apart. Sew in zipper.
3. Sew darts on front. Press bulk towards top.
4. Sew yoke to front, press towards top, serge.
5. Sew side and shoulder seams, press towards the back and serge.
6. Sew the shoulder seams of the neckline facings, press the seam apart. Serge the outer edge. Pin facing to garment right sides together and sew the neckline. Clip into curves, turn facing onto wrong side, straighten, press. Slipstitch to shoulder seams and to zipper tape.
7. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, matching notches, serge.
8. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise and press right side out. Sew cuff to wrong side of sleeve, serge. Fold cuff to right side, press.
9. Serge bottom edge of garment, press onto wrong side and topstitch.
10. Fold belt in half lengthwise right sides together and sew, and leave an opening unsewn along the lower edge, so that you can turn out the piece later. Turn belt right side out, straighten and press. Topstitch belt around all edges at 0.1 cm from the edge.

TECHNICAL DRAWING:

