

Sweatshirt With Pockets - Sewing Pattern #2387

Recommendations on fabric: two sided thick natural/mixed knit fabric of small stretchiness.

You will also need: bias tape. (approximate length is given on the front pattern piece).

Seam allowances: all seams 1 cm; seam allowance for hem of garment and hem of sleeve, seam allowance along the upper edge of one-piece pocket – 0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Stand collar – cut 2

INSTRUCTIONS:

1. Finish the lower edge of the Front with bias tape. Fold the one-piece pocket towards top and topstitch vertically, according to markings. Side edges baste together.
2. Finish the lower edge of Back with bias tape.
3. Sew shoulder seams, sewing the sleeve edges at the same time exactly up to the marking line of one-piece cuff. Clip into seam allowance near the marking. Serge and press towards back. Sew the seam of the one-piece cuff from the right side. Serge and press.
4. Finish the lower edge of Sleeve with bias tape. Sew side seams exactly up to the marking line of one-piece cuff. Clip into seam allowance near the marking. Serge and press towards back. Sew the seam of the one-piece cuff from the right side. Serge and press. Fold one-piece cuff onto right side and baste together along the sleeve edges.
5. Sew the seam of the stand collar. Press the seam allowances apart. Pin together parts of stand collar, right sides together and sew upper edge. Clip seam allowances. Fold away inner stand collar onto wrong side, straighten the seam and press. Sew the stand collar into neckline, serge and press.

TECHNICAL DRAWING:

