

## Jacket With Peplum - Sewing Pattern #4475

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; thin shoulder pads; dress zipper.

Seam allowances: all seams 1 cm. Seam allowance on lower edge of sleeve 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Center front facing — cut 2
6. Back neck facing - cut 1
7. Upper sleeve - cut 2

8. Lower sleeve - cut 2
9. Lower back — cut 1
10. Lower front — cut 2
11. Flap — cut 2

Lining is cut using pattern blocks for main fabric, except for the width of back neckline facing and buttonstands.

Lining:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Front lining - cut 2
5. Upper sleeve - cut 2
6. Lower sleeve - cut 2
7. Lower back — cut 1
8. Lower front — cut 2
9. Flap — cut 2

Fusible interfacing: center front facing, back neck facing, flap.

## **INSTRUCTIONS:**

1. Apply fusible interfacing. Cut a tape from fusible interfacing and apply along edge of back neckline. Apply fusible interfacing to vent area on sleeve.
2. Pin together flap and lining right sides together and sew outer edges. Trim seam allowances, turn right side out and press. Pin flap at lower front according to the notch and baste together.
3. Sew dart on center front. Press bulk towards center. Sew princess seam on front. Press towards center. Sew lower part. Press seam apart.
4. Sew dart on center back. Press bulk towards center. Sew and press apart princess seams on back. Sew center back seam. Press seam apart. Sew lower part. Press seam apart.
5. Sew shoulder and side seams of jacket. Press seam apart.
6. Sew elbow seam on sleeve and corners of vent on lower and upper sleeves. Press elbow seam apart *рукава*, clip into corner of seam allowance and press vent. Press hem of sleeve. Sew and press apart front sleeve seam.
7. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
8. Sew and press apart shoulder seams of back neckline facing and buttonstand. Sew together pieces of lining

in the same way as you have sewn pieces from main fabric, leaving an opening in left elbow seam of sleeve. Sew lining to facing and buttonstands.

9. Pin together jacket and lining right sides together, inserting closure, pin together, matching outer edges. Sew lining to center front, neckline and hem of jacket . Sew lining to hem of sleeve. Turn jacket right side out through the opening. Baste lining to main fabric along waist seam. Sew the opening closed.

### TECHNICAL DRAWING:

