

Summer Dress - Sewing Pattern #4785

Recommendations on fabric: natural/mixed knit fabric of medium stretchiness.

You will also need: elastic tape, its width should equal 0.7 - 1 cm (approximate length is given on the front pattern piece), knit bias tape (approximate length is given on the front pattern piece).

Seam allowances: seam allowance for hem of garment - 1.5 cm, other seams - 0.7 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 - 0.8 cm.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Front - cut 1 on fold

2. Back – cut 1 on fold

INSTRUCTIONS:

1. Sew right shoulder seam. Serge and press towards back.
2. Finish neckline with bias tape.
3. Sew left shoulder seam. Serge and press towards back.
4. Finish armholes with bias tape.
5. Sew side seams. Serge seams and press towards back. Sew short fixing stitches at side seams near armhole.
6. Sew elastic tape into ring. Topstitch elastic tape between the marked lines, stretching it in the process.
7. Serge the lower edge of garment, press onto wrong side and topstitch.

TECHNICAL DRAWING:

