Blouson With Cowl Neck - Sewing Pattern #4811

Recommendations on fabric: natural/mixed knit fabric of small stretchiness.

Seam allowances: all seams 1 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Back – cut 1 on fold
2. Front – cut 1 on fold
3. Collar – cut 1
4. Sleeve – cut 2

Main fabric 1:
1. Back yoke – cut 1 on fold

2. Front yoke – cut 1 on fold
3. Cuff – cut 2
4. Lower placket – cut 1 on fold

INSTRUCTIONS:

1. Sew shoulder seams on yokes. Serge seams and press towards back.

2. Sew side seams. Serge seams and press towards back.

3. Sew sleeve seam. Serge and press towards back. Sew lower sleeve to front and to back. Serge the seam allowances.

4. Sew yoke to self blouson. Serge seams and press towards top.

5. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise right side out and press. Sew cuff to lower edge of sleeve, stretching it to the required length. Press towards top and serge.

6. Sew lower placket into ring, press the seam apart. Pin together lower placket in half lengthwise right side out and press. Sew lower placket to lower edge, stretching it to the required length. Press towards top and serge.

7. Sew collar into a ring, press the seam apart. Fold collar in half lengthwise right side out and press. Sew collar to neckline. Collar seam should be shifted by 2 cm from shoulder seam towards back. Serge the seam allowances.

TECHNICAL DRAWING:

