Knit Blouse With Wrap And Peplum - Sewing Pattern #4899



Recommendations on fabric: natural/mixed knit fabric of small/medium stretchiness.

Seam allowances: all seams 1 cm. Seam allowance along hem – 1.5 cm. Seam allowance along neckline on the back and left upper front – 0 cm. Seam allowance of neckline and middle edge of right upper front – 0 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:
Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Upper back – cut 1
2. Lower back - cut 1
3. Upper right front – cut 1

4. Upper left front – cut 1
5. Lower front – cut 1
6. Sleeve - cut 2

INSTRUCTIONS:

1. Sew darts on back and front, press the bulk of waist darts towards center, press the bulk of bust darts towards top.

2. Sew shoulder seams, press towards the back and serge.

3. Serge center seam of upper left front. Cut (or take ready) bias tape, its width should equal 4 cm and its length should equal, the one mentioned on the pattern block. Fold bias tape in half lengthwise right side out and press. Lay the piece apart, fold longer edges towards center and press one more time. Finish back neckline with bias tape. Finish center edge of upper front with bias tape..
Pin right front onto left front and stitch in the ditch into the seam of bias tape.

4. Sew side edges on lower and upper parts, press towards the back and serge.

5. Sew upper part to lower part, press towards top and serge.

6. Serge lower edge of sleeve, press onto wrong side and topstitch. Sew sleeves into armholes, serge and press.

7. Serge lower edge of garment, press onto wrong side and topstitch.

TECHNICAL DRAWING:

